


INSTALLATION INSTRUCTIONS


Model: **CB1800; CB1802PSX**
Fixture Family: **GIG**
Document Description: Installation Instructions for
GIG Series Luminaires

VISA LIGHTING
AN OLDENBURG GROUP COMPANY
1717 West Civic Drive Milwaukee, WI 53209
414-354-6600
Design Modification Rights Reserved
© Visa Lighting



GIG

**CB1800
CB1802PSX**



Sheet 2: STANDARD INSTALLATION

Sheet 3: BH1 INSTALLATION, Supplemental Bracket Hardware for high abuse

Sheet 4: Wiring diagram CB1800

Sheet 5: Wiring diagram CB1802PSX

Sheet 6: TOUCHDIM TROUBLESHOOTING STEPS

When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Drawing: 762271XX

Rev: G

Sheet: 1 of 6

Eng: CMG


Date Drawn: 2/25/2025

INSTALLATION INSTRUCTIONS

Model: **CB1800; CB1802PSX**
Fixture Family: **GIG**
Document Description: Installation Instructions for
GIG Series Luminaires

VISA LIGHTING
AN OLDENBURG GROUP COMPANY
1717 West Civic Drive Milwaukee, WI 53209
414-354-6600
Design Modification Rights Reserved
© Visa Lighting 2016

STANDARD INSTALLATION



Instructions

1. Make electrical connections according to NEC and local regulations.
2. Attach mounting plate to junction box (by others), using junction box screws (2) provided. Ensure wall gasket is seated underneath mounting plate and is not pinched or crooked.
3. Align fixture housing with mounting plate using the hook and slot feature.
4. Secure fixture housing to mounting plate with housing screws (2) provided. The Nylon Isolation Washers are required for the Touch Dimming option to properly operate.

NOTE:

Ingress protection for fixture is from the outside only. Fixture is not sealed from the junction box or wall cavity. Wall gasket must be installed on a smooth flat surface. Caulking around the housing may be necessary if the wall surface is not smooth.

When using electrical equipment, basic safety precautions should always be followed, including the following:


- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

INSTALLATION INSTRUCTIONS

Model: **CB1800; CB1802PSX**
 Fixture Family: **GIG**
 Document Description: Installation Instructions for
 GIG Series Luminaires


VISA LIGHTING
 AN OLDENBURG GROUP COMPANY
 1717 West Civic Drive Milwaukee, WI 53209
 414-354-6600
 Design Modification Rights Reserved
 © Visa Lighting

BH1 INSTALLATION Supplemental Bracket Hardware for high abuse



Instructions

1. Attach BH1 MOUNT to structure through junction box using #8 or #10 screws (by others). BH1 INSTALL TEMPLATE provided for hole alignment only, remove after BH1 MOUNT is secure.
2. Make electrical connections according to NEC and local regulations.
3. Attach mounting plate to junction box using 1/4-20 screws (2) provided. Ensure wall gasket is seated underneath mounting plate and is not pinched or crooked.
4. For rough service applications #8 supplemental screw (by others) is recommended. See facility manager as they may require Pick-Proof caulk for certain circumstances.
5. Align fixture housing with mounting plate using the hook and slot feature.
6. Secure fixture housing to mounting plate with housing fasteners (2) provided. The Nylon Isolation Washers are required for the Touch Dimming option to properly operate. Take care not to over-tighten, if they are over-tightened & crushed...Touch Dim will not work.



NOTE:

Ingress protection for fixture is from the outside only. Fixture is not sealed from the junction box or wall cavity. Wall gasket must be installed on a smooth flat surface. Caulking around the housing may be necessary if the wall surface is not smooth.

When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Drawing: 762271XX

Rev: G

Sheet: 3 of 6

Eng: CMG


Date Drawn: 2/25/2025

INSTALLATION INSTRUCTIONS


Model: **CB1800; CB1802PSX**
Fixture Family: **GIG**
Document Description: Installation Instructions for
GIG Series Luminaires

VISA LIGHTING
AN OLDENBURG GROUP COMPANY
1717 West Civic Drive Milwaukee, WI 53209
414-354-6600
Design Modification Rights Reserved
© Visa Lighting 2016

CB1800 TOUCH DIMMING (INTEGRAL DRIVER)



CB1800 WIRED DIMMING (REMOTE DRIVER)



When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Drawing: 762271XX

Rev: G

Sheet: 4 of 6

Eng: CMG


Date Drawn: 2/25/2025

INSTALLATION INSTRUCTIONS

Model: **CB1800; CB1802PSX**
Fixture Family: **GIG**
Document Description: Installation Instructions for
GIG Series Luminaires

VISA LIGHTING
AN OLDENBURG GROUP COMPANY
1717 West Civic Drive Milwaukee, WI 53209
414-354-6600
Design Modification Rights Reserved
© Visa Lighting 2016

CB1802PSX TOUCH DIMMING **REMOTE DRIVER**



Drawing: 762271XX

Rev: G

Sheet: 5 of 6

Eng: CMG

Date Drawn: 2/25/2025

When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.


INSTALLATION INSTRUCTIONS

Model: **CB1800; CB1802PSX**
Fixture Family: **GIG**
Document Description: Installation Instructions for
GIG Series Luminaires

VISA LIGHTING
AN OLDENBURG GROUP COMPANY
1717 West Civic Drive Milwaukee, WI 53209
414-354-6600
Design Modification Rights Reserved
© Visa Lighting 2016

TOUCHDIM TROUBLESHOOTING STEPS

1. If this is the first installation or modifications have been made to the installation, be sure to cycle power OFF and then ON to allow fixture to properly self-calibrate
2. Touchdim controlled fixtures should not have the AC supply power switched on/off with an external switch. When power first is switched on to a Gig in touch-dim mode, the output is not always in a “defined” state until the first time someone touches it. That means that the output may be a bit dim or appear to flicker at a high frequency. Once it starts reading touches, it should snap into its defined states of on/dim/off.
3. If issues persist:
 - With the power to the fixture OFF, check continuity between the front housing and ground. There should not be continuity between front housing and ground when fully installed. If continuity is present, **check the condition of the isolating washers beneath the heads of the housing fasteners, and the rubberized wall mounting plate. If these are damaged they must be replaced.**
 - Confirm proper wiring per instructions on sheets 4 & 5.
 - Ensure that the mounting plate ground wire and transient suppressor are both connected to earth ground, ensure the black rubberized coating on the mounting plate is intact & undamaged. Exposed bare metal can cause grounding & touch dimming issues.
 - If the fixture is “touched” continuously for more than 60 seconds (holding or leaning on the fixture etc.), it will recalibrate itself based on whatever is touching it. When that touch is removed the fixture should revert to normal operation. Cycle power if this does not resolve quickly.



When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.