



- 1) Install universal mounting strap to the junction box.
- 2) For 20" long colonnade: locate, drill holes and install anchor nuts for auxillary mounting holes.
- 3) Make electrical connections.
- 4) Install backplate over junction box and secure with thumb nuts provided.
- 5) For 20" long colonnade: fasten the two supplied #8 self tapping screws thru the auxillary mounting holes into the anchor nuts and tighten.
- 6) Caulk around the backplate with a silicone rubber caulk to provide a water-tight seal between the mounting surface and the fixture.
- 7) Place lamps in holders.
- 8) Install lens housing on backplate using #6 allen head screws provided.

When using electrical equipment, basic safety precautions should always be followed, including the following:  
 1) Read all instructions carefully before installing and save for future use. Make sure all connections are in accordance with the National Electrical code and local regulations.  
 2) To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture. Service should be performed by qualified personnel.  
 3) These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.



Milwaukee, WI  
 414-354-6600  
 Design Modification Rights Reserved  
 ©Visa Lighting 2001

INSTALLATION INSTRUCTIONS:  
 Family fixture name: COLONNADE

Description: OUTDOOR COLONNADE

Drawing: 760069XX  
 Rev: A

Sheet 1 of 1  
 Eng: MJR

Date drawn: 1993

Drawing: 760069XX

Rev: A Sheet 1 of 1