



NOTE:
FLUORESCENT LAMPING SHOWN
INCANDESCENT MOUNTS SAME WAY.

1. REFER TO SEPARATE INSTRUCTIONS FOR MOUNTING UNIVERSAL STRAP. (760002XX)
NOTE MAKE SURE THE (2) SCREWS ARE LEVEL AND HORIZONTAL.
2. MOUNT LAMPLATE TO UNIVERSAL STRAP USING (2) 8-32 KNURLD NUTS (PROVIDED).
3. LAMPLATE HAS THREE HOLES FOR ADDITIONAL WALL ANCHORS. (BY OTHER).
4. AFTER THE LAMPLATE IS SECURED TO THE WALL, INSTALL THE LAMP.
5. MOUNT HOUSING ASSEMBLY TO THE LAMPLATE, NOTE: BE SURE THE TOP SUPPORT BRACKET CLEARS THE FLUORESCENT LAMP. THEN SECURE WITH (2) 8-32 SEMS SCREWS (PROVIDED).

When using electrical equipment, basic safety precautions should always be followed, including the following:
 1) Read all instructions carefully before installing and save for future use. Make sure all connections are in accordance with the National Electrical Code and local regulations.
 2) To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture. Service should be performed by qualified personnel.
 3) These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Drawing : 760289
Rev : A **Sheet 1 of 1**


VISA LIGHTING
 An Oldenburg Group Company
 1717 W Civic Drive, Glendale, WI 53209
 (414)-354-6600
 Design Modification Rights Reserved
 ©Visa Lighting 2001

INSTALLATION INSTRUCTIONS: CB6200
Fixture family name: VERRE

Description: INST SHT VERRE MNTG

Drawing : 760289 Sheet 1 of 1
 Rev: A Eng: GG Date drawn: 12/31/1999