
UNITY CEILING RECESSED MOUNT Model: Fixture Family: Document Description: Installation Instructions for CM1900,CM1901,CM1906 Series Luminaires



UNITY


CEILING RECESSED MOUNT

CM1900 CM1901 CM1906

When using electrical equipment, basic safety precautions should always be followed, including the following:
Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
Service should be performed by qualified personnel.
These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

UNITY Model: Fixture Family: CEILING RECESSED MOUNT Document Description: Installation Instructions for CM1900,CM1901,CM1906 Series Luminaires

TYPICAL GRID CEILING RECESSED FIXTURE MOUNTING



'ISA LIGHT

1717 West Civic Drive Milwaukee, WI 53209

414-354-6600 **Design Modification Rights Reserved**

© Visa Lighting


Date Drawn: 07/22/10

- Remove the lens/diffuser assembly from fixture before attempting installation by unlatching 1. one end. Swing frame down/out approximately 45° and unhook hinge. Set assembly aside and reinstall as last step of installation.
- 2. Install the fixture in the T-Bar grid system by lifting the fixture through the opening and lowering it onto the T-Bar grid.
- Install the T-Bar brackets to each of the four corners using the 1/4-20 screws, nuts, and 3. washers.
- 4. Attach the fixture to the T-Bar grid at all four corners with screws through the T-Bar bracket. It may be necessary to drill a hole through the grid members.
- 5. If required, each of the four corners of the fixture can be supported by wires from the T-Bar bracket and attached to the building structure.

CAUTION: The T-Bar grid system must be strong enough to support the fixture.

- When using electrical equipment, basic safety precautions should always be followed, including the following:
- Read all instructions carefully before installing and save for future use.
 Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

UNITY Model: Fixture Family: CEILING RECESSED MOUNT Document Description: Installation Instructions for CM1900,CM1901,CM1906 Series Luminaires



- 1. The thermal protectors are shipped taped to the side of the housing to prevent damage in shipment.
- 2. After installation into the T-Bar grid system, remove the tape and push the insulation detector into the hole in the housing until it snaps into place.
- 3. If the housing has (2) insulation detectors, install the second protector like the first.
- 4. Refer to pages 4 and 5 for how to make the wire connections.

CAUTION: The thermal protectors must not contact the T-Bar grid system.

- Service should be performed by qualified personnel.

SALIGHT

1717 West Civic Drive Milwaukee, WI 53209

414-354-6600 **Design Modification Rights Reserved**

© Visa Lighting

Eng: PAO


Rev:

When using electrical equipment, basic safety precautions should always be followed, including the following:

<sup>Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture Code and local regulations.</sup>

[•] These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Model: Fixture Family:	UNITY CEILING RECESSED MOUNT
Document Description:	Installation Instructions for
	CM1900,CM1901,CM1906 Series Luminaires



Wiring Instructions

- 1. All connections to the fixture except wires from the optional -VIRGB remote driver are at line voltage. Use of a separate control interface (by others), is required to control the fixture by means other than line-voltage switches.
- All AC inputs to fixture must be supplied from the same branch circuit. 2.
- 3. It is not recommended that optional -BSLED lighting be controllable from the patient bed, pillow speaker, or patient-accessible wall controls.
- Ambient line and exam line must both be energized to achieve exam light levels on patient 4. bed surface.
 - When using electrical equipment, basic safety precautions should always be followed, including the following:

 - Read all instructions carefully before installing and save for future use.
 Make sure all connections are in accordance with the National Electrical Code and local regulations.
 To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture


 - Service should be performed by qualified personnel.
 - These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

VISA LIGHTIN

1717 West Civic Drive Milwaukee, WI 53209 414-354-6600 **Design Modification Rights Reserved** © Visa Lighting

Date Drawn: 07/22/10

Model: UNITY Fixture Family: CEILING RECESSED MOUNT Document Description: Installation Instructions for CM1900,CM1901,CM1906 Series Luminaires




When using electrical equipment, basic safety precautions should always be followed, including the following:
Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
Service should be performed by qualified personnel.
These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.



Drawing: 760835XX

UNITY CEILING RECESSED MOUNT Model: Fixture Family: Document Description: Installation Instructions for CM1900,CM1901,CM1906 Series Luminaires


SALIGHTING OLDENBURG GROUP COMPANY 1717 West Civic Drive Milwaukee, WI 53209 414-354-6600 **Design Modification Rights Reserved** © Visa Lighting



DRYWALL INSTALLATION KIT (SRI) FOR RECESSED UNITY

CM1900 CM1901 CM1906

When using electrical equipment, basic safety precautions should always be followed, including the following:
Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
Service should be performed by qualified personnel.
These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.




- 1. SRI frame - Assemble corners as illustrated in Detail A using (3) 8-32 nuts at each corner.
- 2. Slide fixture housing into SRI frame.

- 3. Holding frame to housing securely, hand bend corner strap over top of housing.
- 4. Secure corner straps with #10 screws and nuts through the slot as shown in Detail B.
- 5. Attach drywall yokes to structure around opening.
- Install and adjust 1/4-20 bolts to correct finished length need for flush fixture mounting. 6.
- 7. Attach fixture to 1/4-20 bolts using washers and nuts.

When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
 Make sure all connections are in accordance with the National Electrical Code and local regulations.
 To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
 Service should be performed by qualified personnel.
 These instructions mate cover all details or variations. If additional information is peeded, place contact V

• These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.



REF FIXTURE WIDTH CROSS SECTION VIEW

22.0 for 2x2

46.0 for 2x4

1. Attach DRYWALL YOKES to structure around opening (match spacing to holes in housing).

REF TOP VIEW

- 2. Stud spacing as shown above for 9"x4, 2x2 and 2x4 fixtures.
- 3. Adjust stud length such that bottom of stud is approximately 2.9" from ceiling surface
 - When using electrical equipment, basic safety precautions should always be followed, including the following:
 Read all instructions carefully before installing and save for future use.
 Make sure all connections are in accordance with the National Electrical Code and local regulations.
 To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
 Service should be performed by qualified personnel.
 These instructions must environ all details are variations.

ò

0

n

 $\infty \infty \infty$

(2.9)

STUD SPACING AS SHOWN ABOVE

• These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Sheet: 8 of 8 Eng: PAO

Drawing: 760835XX

Rev:

 \times

đ

ò

0

Ω

Date Drawn: 07/22/10

Drywall yoke