
INSTALLATION INSTRUCTIONS

CP4341, 4343, 4345, 4347, 4349, 4351, 4901, 4911 Model: Fixture Family:

Cylinder/Midland Arts LED

Document Description: Installation Instructions for Cylinder/Midland Arts LED

LED Series Luminaires



CYLINDER/MIDLAND ARTS LED

CP4341 **CP4343 CP4345 CP4347 CP4349 CP4351** CP4901

CP4911

*VIEW SHOWN MAY VARY

SPECIAL NOTE: INSTRUCTION PACKET HAS MULTIPLE PAGES, READ CAREFULLY AS INSTRUCTIONS MAY DIFFER DEPENDING ON OPTIONS ORDERED

Pg 2 - Installation Instructions

Pg 3 - General Maintenance features - access to internal components

When using electrical equipment, basic safety precautions should always be followed, including the following:

Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
Service should be performed by qualified personnel.
These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.


INSTALLATION INSTRUCTIONS

CP4341, 4343, 4345, 4347, 4349, 4351, 4901, 4911 Model: Fixture Family:

Cylinder/Midland Arts LED

Document Description: Installation Instructions for Cylinder/Midland Arts LED

LED Series Luminaires



When using electrical equipment, basic safety precautions should always be followed, including the following:

Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
Service should be performed by qualified personnel.
These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.


CP4341, 4343, 4345, 4347, 4349, 4351, 4901, 4911 Model: Fixture Family:

Cylinder/Midland Arts LED

Document Description: Installation Instructions for Cylinder/Midland Arts LED


LED Series Luminaires


MAINTENANCE FEATURES



TUBE HOOK / DMX PORT

To support the Acrylic Tube for maintenance, lift the Acrylic Tube to access the Tube Hook. Swing the Tube Hook up and rest the Acrylic Tube on the Hook.





INSTRUCTIONS TO ACCESS INTERNAL COMPONENTS

- 1) See Tube Hook detail for supporting Acrylic Tube
- 2) Remove (2) Hex Nuts to remove Downlight Bezel
- 3) Twist Downlight Reflector counter clockwise to remove it
- 4) Remove (4) Hex Nuts to remove Tube Support
- 5) Remove (2) Hex Screws attaching the door of wire body and pivot it open

When using electrical equipment, basic safety precautions should always be followed, including the following:

When using electrical equipment, basic safety precautions should always be followed, including the following.
Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture
Service should be performed by qualified personnel.
These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.