
INSTALLATION INSTRUCTIONS

OW1340-58 Model: Fixture Family: **OUTDOOR RAVEN** Document Description: Installation Instructions for

RAVEN Series Luminaires





RAVEN OUTDOOR

OW1340 OW1342 OW1344 OW1346 OW1348 OW1350 OW1352 OW1354 OW1356 **OW1358**

PAGE 2: GENERAL INSTALL

PAGE 3: CAULKING INSTRUCTIONS

When using electrical equipment, basic safety precautions should always be followed, including the following:

• Read all instructions carefully before installing and save for future use.

• Make sure all connections are in accordance with the National Electrical Code and local regulations.


• To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture

• Service should be performed by qualified personnel.

• These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Model: Fixture Family:

OW1340-58 **OUTDOOR RAVEN** Document Description: Installation Instructions for **RAVEN Series Luminaires** 1717 West Civic Drive Milwaukee, WI 53209 414-354-6600 Design Modification Rights Reserved © Visa Lighting



- Carefully remove outer lens by loosening the screws on each side of end cap. Remove 1. the inner lens from fixture and set aside.
- 2. Remove the lamp plate assembly from the housing by removing the lamp plate screws.
- 3. Secure the housing to the junction box with junction box screws (by others). Make sure fixture is level or plum, depending on the orientation, and mark the holes on the mounting surface for the wall anchors using the mounting holes on the housing.
- 4. Remove housing from junction box (by others). Drill holes in mounting surface for the wall anchors.
- 5. Caulk the back of the housing. See page 4 for caulking details.
- 6. Reinstall housing to junction box with junction box screws (by others), and secure to mounting surface with wall mounting screws.
- 7. Make wire connections according to local and national codes. Install lamp plate assembly and secure using the lamp plate screws.
- Carefully install the inner lens into the clips on the lamp plate assembly. 8.
- Install lens assembly by pulling top of cast end caps in direction of arrows and push lens 9. into gasketing in back plate assembly (See page 3 for instructions). Be sure that lens assembly is seated against the gasket and secured by the end caps.

When using electrical equipment, basic safety precautions should always be followed, including the following:

Read all instructions carefully before installing and save for future use.
Make sure all connections are in accordance with the National Electrical Code and local regulations.
To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture

Service should be performed by qualified personnel.


• These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

INSTALLATION INSTRUCTIONS

OW1340-58 Model: **OUTDOOR RAVEN** Fixture Family:

Document Description: Installation Instructions for **RAVEN Series Luminaires**





When using electrical equipment, basic safety precautions should always be followed, including the following:

• Read all instructions carefully before installing and save for future use.

• Make sure all connections are in accordance with the National Electrical Code and local regulations.

• To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture

• Service should be performed by qualified personnel.

• These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.